










# RICO


## Závesná skrinka




P - 16




A - 2




R - 4  
4 x 35 mm




H - 4



F - 4




N - 4  
4 x 27 mm



U - 4




G - 8  
4 x 16 mm




Z - 1




E - 10



C - 8




D - 4




W - 1



B - 20




K - 32




L - 32


1



2



3



4

